Finish
Dishwasher Cleaner

SKU: 33-271 | 8X250ml
Fragrance: Fruity
pH: 1.3 - 1.7
Colours: Blue, yellow, orange
Appearance: Liquid

Finish Dishwasher Deep Cleaner delivers an intensive clean to help restore and maintain peak dishwasher performance and support consistently sparkling results. The easy-to-use formula tackles hidden deposits and residues that accumulate over time, helping to prevent blockages and keep the machine running efficiently. Trusted by leading dishwasher brands, it provides a reliable solution for effective dishwasher maintenance.

- Advanced clog-dissolving technology effectively removes grease, residues and limescale build-up in pipes, drains and filters.
- Deep cleans hard-to-reach internal components.
- Eliminates unpleasant odours to leave dishwashers smelling clean and fresh.
- Effectively removes soiling in hard water areas.
- Ideal for both domestic and commercial dishwashers.
- Sealed bottle to prevent leakage.



AREAS OF USE

Commercial Kitchens

Catering Facilities

HOW TO USE

1. Empty dishwasher and remove debris from filter.
2. Peal off sticker from cleaner bottle cap. Do not remove the cap.
3. Position bottle upside down in the silverware basket/bottom dish rack.
4. Close dishwasher and run on high temperature of at least 60^{0}C. Do not add any other detergent or cleaning agent to the wash.
5. After the full cycle has finished, open dishwasher and remove bottle and recycle.
6. For stubborn build-up, repeat the process if necessary.

CONCENTRATION & PACKAGING

RTU

Recyclable Packaging

ARROW COUNTY SUPPLIES
Arrow House, Longden Road, Shrewsbury, SY3 9AE
01743 283600 | response@arrowcounty.com | arrowcounty.com