



Scan Here

Andarta Floor Polish Stripper

SKU: 40-111 | 5ltr

Fragrance: Un-fragranced

pH: 13.5

Colour: Colourless

Appearance: Thin liquid

- Formulated to remove old floor polish.
- Easily lifts aged polish from floors
- Allows mopping away residue quickly and easily.
- Strips metalised or non-metalised polish from rubber, sealed wood, terrazzo & thermoplastic floors.

AREAS OF USE



General



Wooden Floor

USAGE



Use in floorcare machines

ENVIRONMENTAL & PACKAGING



GREENLEAF
APPROVED



CAP
PET
Recyclable



30%



USER FRIENDLY
PACKAGING

HOW TO USE

General Use 1:10

Heavy Deposits 1:5

Apply generously with a mop. Work in and allow to dwell for 5 minutes. Do not allow to dry. Machine scrub with a stripping pad. Mop up loosened polish. For faster results remove with a wet-vac. Allow floor to dry, then mop again to lift any remaining residue before applying polish.



Floor Polish
Stripper

Labour saving floor polish stripper formulated to remove old floor polish. Easily lifts aged polish from floor allowing you to mop away residue quickly and easily.

Directions for use: To remove cap: Place bottle on a firm flat surface. Grip cap and turn anti-clockwise. To replace cap: Grip cap and screw clockwise until tight. Dilute 1:10 for general use. Use 1:5 for heavy deposits. Apply generously with a mop. Work in and allow to dwell for 5 minutes. Do not allow to dry. Machine scrub with a stripping pad. Mop up loosened polish. For faster results remove with a wet-vac. Allow floor to dry, then mop again to lift any remaining residue before applying polish.

CONTAINS: Disodium Metasilicate, Tetrasodium Ethylene Diamine Tetraacetate, Alcohols, C12-14, Ethoxylated, Sodium Hydroxide.

DANGER: Causes severe skin burns and eye damage. Wear protective gloves/protective clothing/eye protection/face protection. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTRE/doctor. Dispose of contents/container in accordance with national regulations.

FOR PROFESSIONAL USE ONLY.
Safety Data Sheet available upon request.
Store in original container in a cool, dry place.



5 056231 004923

Arrow County Supplies, Arrow House, Longden Road, Shrewsbury, Shropshire, SY3 9AE | Tel: 01743 283600 | Email: sales@arrowcounty.com

andartaproducts.com
UFI: KSRQ-A65N-CP7G-8M58

5Le
40-111
200-300-1117



Made in UK